

SAFE-AID TS 7000 FOR MOBILIFT TC48 OPERATORS MANUAL

! WARNING !

THE PURPOSE OF THIS MANUAL IS TO PROVIDE THE CUSTOMER WITH THE OPERATING PROCEDURES ESSENTIAL FOR THE PROMOTION OF PROPER MACHINE OPERATION FOR ITS INTENDED USE. THE IMPORTANCE OF PROPER USAGE CANNOT BE OVERSTRESSED. ALL INFORMATION IN THIS MANUAL SHOULD BE READ AND UNDERSTOOD BEFORE ANY ATTEMPT IS MADE TO OPERATE THE MACHINE.

SINCE THE MANUFACTURER HAS NO DIRECT CONTROL OVER MACHINE APPLICATION AND OPERATION, CONFORMANCE WITH GOOD SAFETY PRACTICE IN THIS AREA IS THE RESPONSIBILITY OF THE USER AND HIS OPERATING PERSONNEL.

ALL PROCEDURES ARE BASED ON THE USE OF THE SYSTEM UNDER PROPER OPERATING CONDITIONS, WITH NO DEVIATIONS FROM THE ORIGINAL DESIGN. ALTERATION AND OR MODIFICATION OF THE EQUIPMENT IS STRICTLY FORBIDDEN WITHOUT PRIOR WRITTEN APPROVAL FROM ELEC-MECH (PTY) LTD.

THE SAFE-AID TS7000 (RATED CAPACITY INDICATOR (RCI)/LOAD MOMENT INDICATOR (LMI)) IS ONLY TO BE REGARDED AS AN AID TO THE OPERATOR. WHEN THE PARAMETERS ARE SET CORRECTLY, THE INDICATOR WILL WARN THE CRANE OPERATOR OF AN APPROACHING OVERLOAD CONDITION OR A CONDITION THAT COULD CAUSE DAMAGE TO EQUIPMENT, PROPERTY, AND/OR INJURY TO THE OPERATOR OR THE SITE WORKERS IN THE VICINITY OF THE CRANE AND ITS LOAD.

THIS SYSTEM UNDER NO CIRCUMSTANCES MUST BE USED AS A SUBSTITUTE FOR THE GOOD JUDGEMENT OF A CRANE OPERATOR WHEN CARRYING OUT APPROVED CRANE-OPERATING PROCEDURES, THEREFORE THE RESPONSIBILITY FOR THE SAFE OPERATION OF THE CRANE LIES WITH THE CRANE OPERATOR. THE SYSTEM WILL NOT NECESSARILY PREVENT DAMAGE DUE TO OVERLOADING AND RELATED CAUSES, IF NOT SET PROPERLY.

BEFORE OPERATING A CRANE EQUIPPED WITH A SAFE-AID TS7000 RCI THE OPERATOR MUST READ THE INFORMATION IN THIS MANUAL CAREFULLY. CORRECT FUNCTIONING OF THE SYSTEM DEPENDS UPON ROUTINE DAILY INSPECTION AND ANY SUSPECTED FAULTS OR APPARENT DAMAGE SHOULD BE IMMEDIATELY REPORTED TO THE RESPONSIBLE PERSON BEFORE USING THE CRANE.

Contents

SYSTEM USE.....	3
SYSTEM STARTUP – FIGURE 2	4
PROGRAM SELECTION – FIGURE 3	5
OPERATING SCREEN – FIGURE 4.....	6
ERROR MESSAGES - FIGURE 5	8
WORKING OPERATIONS.....	10
INDICATING STATUS LIGHTS AND DUMP OUTPUT (LEVER CUT-OFF) - TABLE 2	11
TOUCH SCREEN CALIBRATION – FIGURES 6, 7 & 8	12
QUICK USE FLOW CHART	14
CONTACT DETAILS.....	15

SYSTEM USE

The TS7000 unit is designed with ease of operation in mind. The crane setup is selected and confirmed by the operator before the system goes into its normal operating/monitoring screen requiring no further input from the operator unless the crane configuration changes. Before this is done the crane will remain in safe mode, i.e. the dump circuit will be operational. All inputs to the system are done by the operator via the touch screen including the buzzer override function and momentary bypass. The touch screen is sensitive to touch therefore it is **not** necessary to **push hard** on the screen (*if touch screen does not work or selects incorrectly see **touch screen calibration***).




Figure 1

SYSTEM STARTUP – FIGURE 2

The TS7000 display (LMI) automatically starts up when the crane is powered on, the buzzer will sound intermittently and the green, amber and red VISUAL INDICATION BLOCKS will flash. The system initially runs through a set of internal diagnostics (Figure 2) to make sure all inputs and outputs are working correctly.




Figure 2

PROGRAM SELECTION – FIGURE 3

Each program can be selected by pushing on the program name that is required this will highlight the selected program. If needed scroll down through the programs either using the up and down arrow keys or by running a finger up and down on the scroll bar on the left of the screen. This will enable scrolling through all the programs. Once the applicable program has been highlighted, press the **Select** button to select the desired program.

The Mobilift TC48 has been programmed & calibrated with the following programs:

- HOOK 1 – The hook closest to the crane operator
- HOOK 2
- HOOK 3
- HOOK 4
- MANUAL EXTENSION – when the manual (pinned) section is extended.

Cranes are designed to utilise the boom length and angle to maximise lifting capacities so therefore **DO NOT** select the HOOK programs under circumstances if the manual is extended as this will affect the boom weight and cause incorrect lifted load readings.

The correct selection of the program is imperative as this determines the correct rated capacities and work areas. If selected incorrectly, a higher rated capacity than allowed could be selected for that crane configuration OR the incorrect lifted load could be displayed, this is very dangerous as it can cause the boom to bend / break or the crane to tip / fall over.




Figure 3

OPERATING SCREEN – FIGURE 4

All the crane and system information can be viewed from here including all the parameters selected from power up. Should a different program need to be selected, press the crane graphic on the screen, the system will go back to the beginning as on system start up. Repeat the steps above.




Figure 4

In operating mode, you can see all the current parameters of the crane.




Area Selection: This is not user selectable and shows the current area the crane is working in, in the case of a Mobilift which cannot slew this will not change.



Length: This displays the current total main boom length including manual section if extended.



Main Angle: This displays the main boom angle.



Radius: This is the current radius from centre line of rotation to the centre of the hook block (load) if the hook block (load) is hanging straight down.



Lifted Load: This is the load on the hook at the present time, if the green light and the load are flashing it is a tare load (the tare has been pressed).



Rated Capacity: This is the load allowed to be picked up with the selected configuration at that current radius as specified by the manufacturer.



Utilisation: Percentage utilization is the percentage of rated load used by the current lifted load. This is also displayed graphically by the bar, going from green (0% - 89%), then amber (90% - 99%) and finally red (100% and above) increasing incrementally with the percentage utilization.



Program: This is the current program selected. Any error messages will be displayed in this block (see Figure 10 – i.e. Anti-2-Block). If there is more than one error, it will scroll across the block.

ERROR MESSAGES - FIGURE 5 & TABLE 1

The TS7000 will sound a buzzer and the green block will be replaced by an orange or red block at the top of the screen if any error occurs on the system. These errors are displayed at the bottom of the screen e.g. Anti-2-Block where program selection is normally displayed, if more than one error occurs the errors will scroll on the bottom until rectified.




Figure 5

Table 1


ERROR	INDICATION	SOLUTION
90% Loading	90-99% of the rated capacity has been reached.	Work carefully you are working at the cranes limit.
100% Loading	The maximum rated capacity has been reached – you are in overload.	Move load into safe working position boom up/down or retract boom.
No Load Chart Data	You are working out of the manufactures specified working range - incorrect working radius	Lower Boom to within the manufacturers specified working range.
No Data	Pressure Error	Contact Installer
Length Exceeded	The length allowed for your selected configuration has been exceeded or the length is above the maximum manufacturer's specified length.	Retract boom or check program selection correct. TS7000 needs calibration - call installer.
Extend Boom	You are working below the specified working length for the selected boom configuration.	Extend boom to the correct working length – check program selection correct.
High Angle	The angle of the boom is above the crane manufacturer's maximum specification.	Lower boom – Check TS7000 calibration.
Low Angle	The angle of the boom is below the crane manufacturer's minimum specification.	Raise boom – Check TS7000 calibration.
Mother Board NC	No communication between mother board and display.	Check cabling – call installer.
Main Angle NC	No communication between main angle board and motherboard/display.	Check cabling – call installer.
Key Switch Override	The key switch has been turned to the override position - key cannot be removed.	Turn key to the position where the key can be removed. Remove key for safe use.
Main Dump Short	Short circuit on the dump circuit.	Check dump solenoid coils and dump wiring
Main Dump Open	Dump circuit is open circuit.	Check solenoid plugs are connected.
Bottom Pressure Low	Bottom pressure transducers reading is below 4mA	Check bottom pressure transducer - Replace if defective.
Top pressure Low	Top pressure transducers reading is below 4mA	Check top pressure transducer - Replace if defective.
Length Zero Error	Length potentiometer is reading below minimum allowed reading.	Check length potentiometer wiring - replace potentiometer or call installer.


For all the errors we have given indication of the problem and the common solutions, these can be done by the operator or an individual who has some basic crane knowledge. If the given solution does not work please contact the original installer or someone from our service network where we can try and help telephonically or send a technician to repair the system.


WORKING OPERATIONS


As an operator, there are **FIVE** different areas/places on the operating screen which can be pressed to initiate a function.

1. **The top left hand corner.** This is to get into calibration mode – this enters into the PROGRAMMING screen that will ask for a password (see calibration manual). To return to the working screen press Enter.
2. **The Tare** which is activated by pressing directly on the lifted load when a load is displaying on the hook. The Lifted Load will be zeroed allowing for a reading excluding the original weight. The original weight is still taken into account when calculating the percentage of utilization therefore the TS7000 will still give the correct 90% and 100% warnings. Once pressed the numbers under the lifted load will flash showing no value, only 0,0t and the GREEN BLOCK will flash intermittently. Thereafter, if a weight is lifted, only the weight lifted will be displayed and not the weight together with hook block or any other additional weight. To return to the actual load, press the lifted load again, it will stop flashing showing the actual load on the hook.

3. **The buzzer override** which is located in the **bottom left** of the screen  5 seconds after an error condition occurs. When the buzzer override is pressed the AMBER BLOCK

will flash intermittently a red cross will be placed through the buzzer picture  and the buzzer will shut off. The buzzer override is needed for each alarm condition this means if you have overridden one error and another occurs the buzzer will sound again.

4. **The program selection** is the crane graphic on the screen.  If at any given time the current program needs to be changed, press on the crane graphic and this will return to the first selection as if powering up for the first time. For example, if the crane is working Hook 1 and now the manual extension is required, immediately change the program to Manual Extension as the cranes rated capacities, limits and lifted load will be different.

5.  **The momentary override** which is the utilisation bar graph on the screen. By holding your finger anywhere in this area the dump solenoids (lever cut-off) can be overridden momentarily (while pushing on the screen in that area) to allow the crane to be folded up.

Note: This function can only be used if activated by the installer.

INDICATING STATUS LIGHTS AND DUMP OUTPUT (LEVER CUT-OFF) - TABLE 2

There are **three BLOCKS** that are illuminated like a traffic robot situated on the top of the display screen.



These **BLOCKS** are illuminated depending on the working state and error conditions. These **BLOCKS** are a basic way of checking the LMI.

The following chart gives you the **BLOCK** status, buzzer status as well as the status of the **DUMP** (Lever Cut-off). **DUMP** the crane will cut-out and **NO DUMP** you are able to work. To rectify or check the error, please check the error message chart (Table 1) on page 14 & 15.

When the system is in the correct working condition (no errors), the GREEN BLOCK will be permanently on.

Table 2

SYSTEM MESSAGE	BLOCK STATUS	DUMP STATUS	BUZZER STATUS
No Selection	ALL FLASHING	ON	INTERMITTENT
High Angle	RED	ON	ON
Low Angle	RED	ON	ON
Length Exceeded	RED	ON	ON
Extend Boom	ORANGE	OFF	MEDIUM
M400 NC	RED	ON	ON
Main A400 NC	RED	ON	ON
Overload	RED	ON	ON
≥90% Loading	ORANGE	OFF	MEDIUM
No Load Chart Data	RED	ON	ON
No Moment Value	RED	ON	ON
Main Dump Short	RED	ON	ON
Main Dump Open	RED	ON	ON
No Dump Supply	RED	ON	ON
Keyswitch Override	RED	ON	ON
Length Error	RED	ON	ON
P/Tdx Bottom Error	RED	ON	ON
P/Tdx Top Error	RED	ON	ON

NOTES:

- The **amber BLOCK** will flash when buzzer override is activated, and if a new error occurs the buzzer will be reactivated and will have to be overridden again.
- The **green BLOCK** will flash when TARE function is used and the crane is within the limits specified by the manufacturer, if not normal errors will resume.

TOUCH SCREEN CALIBRATION – FIGURES 6, 7 & 8

If the screen is not responding correctly to touch the touch screen may need to be calibrated.

Switch the TS7000 system power off then power up the TS7000 and wait for the splash screen (Figure 11) to appear.




Figure 6

While the splash screen is on (Figure 6), press and hold the screen for five full seconds in the centre until the touch calibration is activated and loaded (Figure 7).




FIGURE 7




FIGURE 8

If the calibration screen has been entered by accident and touch calibration is not necessary, press the **Exit** button without pushing anywhere else on the screen. This takes you out of the touch screen calibration and back to the normal operations.

If touch calibration is required follow the below procedures:

Press and hold finger where the two lines meet inside the small box (Figure 7 bottom left hand corner). Calibration works fine when using a finger but for better results use a pen taking care not to press too hard or you will damage the screen.

Hold finger/pen in this area until prompted to lift (Figure 8). The software will then ask for three more touch zones resulting in co-ordinates for all four corners of the screen.

Once calibration is complete the software automatically goes to the first selection screen.

QUICK USE FLOW CHART

